#### WAC Home - 288W Power Supply

### **Power Supply Units**

This product must be installed in accordance with all applicable national and local electrical and construction codes by a person familiar with the construction and operation of the product and the hazards involved. Failure to comply with the following installation instructions may result in death or serious injury.

#### CAUTION

Fully disconnect power before installation is started to prevent injury due to electrical shock.

Inspect all parts for visible damage before installation. Cease installation if damage is found.

Do not exceed the safety-rated voltage of the unit.

Do not strip an excessive amount of sheathing from any wiring.

Any modifications of any kind will fully void the product's warranty.

Ce produit doit être installé conformément à toutes les réglementations électriques et de construction nationales et locales en vigueur, par une personne familiarisée avec la construction et le fonctionnement du produit, ainsi qu'avec les dangers qu'il présente. Le non-respect des instructions d'installation suivantes peut entraîner des blessures graves, voire mortelles.

#### PRUDENCE

Débranchez complètement l'alimentation avant de commencer l'installation afin d'éviter tout risque de choc électrique.

Inspectez toutes les pièces avant l'installation pour déceler tout dommage visible. Arrêtez l'installation en cas de dommage.

Ne dépassez pas la tension nominale de sécurité de l'appareil.

Ne dénudez pas excessivement les câbles.

Toute modification, quelle qu'elle soit, annulera la garantie du produit.

## **Installation Preparation**

#### **Required tools**




**#2 Phillips Screwdriver** 




20AWG Wire Stripper

#### **WAC Home 288W Power Supply**




## **Component Diagram**




#### **WAC Home - 288W Power Supply**

### **Power Supply Units**









## **Installation Procedure**





Mount the included antenna to the power supply unit by screwing it into the intended port on the top face of the unit, opposite the three exterior connectors.






Mount the power supply unit to any indoor surface that is distanced from heat sources and is easily accessible for servicing. The screw holes for mounting are located on each side of the case.

#### **WAC Home - 288W Power Supply**


### **Power Supply Units**






Use a #2 Phillips screwdriver to remove the two (2x) button head screws that are securing the wiring compartment cover, which is the smaller of the two.





Remove a knockout from the wiring compartment and install the Romex connector with the provided locknut. Insert the Romex cable through the connector, securing it with the integral cable clamp. Splice the black Romex wire to the black wire from the power supply, the white Romex wire to the white wire from the power supply, and the green or bare copper Romex wire to the green wire from the power supply. All connections should be done with wire nuts.






Connect the wiring for the desired output to the appropriate terminals located on the outside of the power supply unit.

Output Type	Red Terminal	Black Terminal
Static White (No CCT Adjustment)	+ (24VDC Positive)	- (Negative)
Tunable White (1800K-4000K)	18	40
Tunable White (2700K-5000K)	27	50

#### **WAC Home - 288W Power Supply**

## **Power Supply Units**






Slide the cover of the wiring compartment back on and retighten the screws with the #2 Phillips screwdriver.


# **Setup Procedure**





After checking the installation, reconnect and turn the power to the system on.





Initiate the pairing mode for the WAC Home system by quickly pressing the black WAC-Mesh button three times. The unit will then enter pairing mode which allows the MyWAC app to link to the system.

#### **WAC Home - 288W Power Supply**

### **Power Supply Units**






The unit will be in pairing mode for 10 minutes. If the process does not complete in that time, repeat Step #2 of the Setup Procedure.

Download the MyWAC App from the App Store (Apple) or Google Play (Android), and follow the in-app instructions to complete the setup and customize your lighting fixtures.

## **Troubleshooting**



If needed, press the WAC-Mesh button six times to reboot the unit and press the WAC-Mesh button ten times to perform a factory reset.





#### **WAC Home - 288W Power Supply**

### **Power Supply Units**

## **Wiring Schematics**

Note: Dimming function will evenly dim all three output channels.





Note: A WallStation's power connection is flexible. It can operate as a standalone system using a separate wiring configuration, or it can connect directly to the power supply for enhanced functionality. This direct connection provides significant advantages: it enables a servicing air-gap on/off switch, allows for pre-configured scene settings, and facilitates automatic pairing with the power supply without requiring the MyWAC app.